



Volumizing Lip Treatment with Fiflow® BTX

Easy cold process lip treatment with Fiflow® as active ingredient. Fiflow® is gas carrier with wrinkle reducing effects. Fiflow® plumps up the skin surface and creates smoother, fuller appearance on lips. Creagel® Crystal HPB together with Creagel® Crystal AF forms a long lasting, water resistant, high shine film on the lips. Creagel® Crystal products are ideal for lip gloss applications as their pseudoplastic behaviour keeps the lip gloss on the lips and stops bleeding around the lip area. Creagel® Crystal allows high pigment loading as it forms a structure which holds the pigments preventing the sedimentation of the particles. Creasil® 11 ID dries off creating a water resistant film which improves the long lasting qualities. Creasil® TDTM adds high shine benefits upon application.

Ingredients	INCI Name	Qty%	Supplier
Phase A			
Creagel® Crystal HPB	Hydrogenated Polyisobutene (and) Ethylene/Propylene Copolymer	31,50	1)
Creasil® TDTM	Tridecyl Trimellitate	31,50	1)
Creagel® Crystal AF	Hydrogenated Polydecene (and) Ethylene/Propylene Copolymer	25,20	1)
Creasil® 11 ID	Isododecane (and) Dimethicone (and) Polyethacrylate	1,80	1)
Phase B			
Fiflow® BTX	Perfluorohexane (and) Perfluoroperhydrophenanthrene (and) Perfluorodecalin (and) Perfluorodimethylcyclohexane	10,00	1)

Procedure:

1. Mix all ingredients in phase A together. No heating necessary.
2. Add phase B into phase A and high shear mix it carefully for 1-2 minutes.

Suppliers:

- 1) CIT SARL